

BOLT ACTION RECEIVER MACK BROTHERS EVO

 \Box

 \bigcup


WARNING

ALWAYS INSURE THE FIREARM IS UNLOADED AND ON SAFE

1. Fitting a barrel to the receiver must be performed by a competent gunsmith and the threaded tenon specifications supplied should be confirmed before any barrel and chamber fitting is performed.


2. This warranty covers any defects in workmanship and materials for the lifetime of the original owner. This warranty does not cover damage to the firearm caused by hand-loaded ammunition, misuse, negligence, abuse, modifications not related to manufacturing defects.

DISCLAIMER OF LIABILITY3. Mack Brothers assumes no liability for damage and or injuries that result in whole or in part from improper installation, product malfunctions, negligent, criminal, improper use, and reloaded or defective ammunition.



 \Box

 \Box




В


Extractor Removal

Removal:

With bolt face toward you, slide flat head screw driver under extractor lip and push extractor away from bolt. Be careful not to mar the face of the bolt. While extractor is being pushed away from bolt, lift extractor up to unseat the extractor and continue lifting up until the extractor is completely removed.

В





Replacement (No Tools Needed):

DETAIL A
SCALE 2: 1

To replace extractor, insert extractor into bolt body groove. Press into place until extractor is seated flush with bolt face.

	NAME	DATE	Mack Brothers				
DRAWN	SSM	8/11/17	Mack Diomeis				
CHECKED			TITLE:				
ENG APPR.			EVO Bolt Instructions				
MFG APPR.							
Q.A.							
COMMENTS:			SIZE	DWG. NO. 2			REV 1
			SCALE:		WEIGHT:	SHEET 2 OF 2	

Α

EVO Bolt Instructions

Removing the firing pin assembly from the cocked position, Figure 1:

With the bolt shroud facing you, rotate the shroud and firing pin assembly 90deg. Clockwise. Firing pin assembly will pop out as shown in Figure 2.




B

В




Firing pin removal:



Remove both set screws using a 1/16" hex wrench. Screws are 6-32 set screws. To remove firing pin, unthread firing pin from cocking piece after set screws are removed. **Spring and pin are under spring load.**

When replacing the firing pin, align indent in firing pin thread with hole in cocking piece and secure with both set screws in the indent. **Use Blue Loctite on last set screw only.**



2

•